

Spare Parts


ThinkTop V50



Table of contents

The information herein is correct at the time of issue but may be subject to change without prior notice	

1. ThinkTop V50 Series 4



Pos	Qty	Denomination	
50 Series			
1	1	Cover	9615376201
2	1	V-ring	9615451401
3	1	Screw, Torx 10	9611996072
4	1	Solenoid valve 1x3/2	9615395701
5	1	Control board, 24V Digital	9615394901
	1	Control board, AS-I 2.11 (31 node)	9615395001
	1	Control board, AS-I 3.0 (62 node)	9615395101
	1	Control board, IO-Link	
8	1	M12 plug, AS-I, 4 pins/2 wires, Hex 17	
	1	M12 plug, IO-Link, 4 pins/3 wires, Hex 17	
	1	M12 plug, DIO, 8 pins/6 wires, Hex 17	Please see note
9	1	Cable gland, Main entry, Ø4-10mm, Hex 19	
9.1	1	Cable gland, Main entry, AS-I, Ø3,5-7mm, Hex 19	
10	2	Air fitting, straight, Ø6mm, Hex 4	
	2	Air fitting, straight, 1/4", Hex 5	
12	1	Air fitting, elbow, Ø6mm	
	1	Air fitting, elbow, 1/4"	
13	1	Exhaust plug, Hex 12	
14	2	Set screw, Hex 2,5	
15	1	Gore vent	
16	1	X-ring	
17	1	Sensor target	9615397601

NOTE: Further information can be found in the product catalogue "Close at Hand", under accessories.

(900729/2)

This document and its contents is owned by Alfa Laval Corporate AB and protected by laws governing intellectual property and thereto related rights. It is the responsibility of the user of this document to comply with all applicable intellectual property laws. Without limiting any rights related to this document, no part of this document may be copied, reproduced or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), or for any purpose, without the expressed permission of Alfa Laval Corporate AB. Alfa Laval Corporate AB will enforce its rights related to this document to the fullest extent of the law, including the seeking of criminal prosecution.

How to contact Alfa Laval Contact details for all countries are continually updated on our website.

© Alfa Laval Corporate AB

Please visit www.alfalaval.com to access the information directly.